



**Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker**



# Setting Up Your




Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker

## *3 Simple Steps to Set-Up and Protect*



Download the  
HOMEi  
App



Mount Flood  
Light Bar on  
any interior or  
exterior wall



Connect your  
Flood Light Bar to  
the App by scanning  
the QR code

**NOTE:** To ensure proper use of your Flood Light Bar with Wi-Fi® Amplifier, Camera & Sound Speaker please follow the instructions detailed in this set-up guide.

# Setting Up Your



Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker

## Step 1: Download the HOMEi App

1. Download the **HOMEi** app in the Apple® App Store, Google® Play Store, or use your phone camera to scan the QR code below to open the app store of your mobile phone.

Apple® App Store or  
Google® Play Store



Scan Code



# Setting Up Your



Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker

## Step 1: Download the HOMEi App

1. In order for your Flood Light Bar to work properly, select **Allow** if you see the prompt: **HOMEi** would like to find and connect to devices on your local network.
2. Create your account and select **Continue**.
3. Follow the App prompts to set up your password and register your camera/device. Then **Log In** to your **HOMEi** app.

**Passwords must contain numbers and letters, be no less than six digits, and cannot contain special characters.**

### **FORGOT PASSWORD:**

In the App click on “Forgot Password” and follow the account retrieval process. You will receive an email with a temporary code. Enter the temporary code. You will receive a second email with your password.





## Step 2: Mounting your Flood Light Bar


1. Use the provided screws to secure the mounting plate to a wall.
2. Attached Flood Light Bar to the mounting plates. Then add an additional line that states: Plug into an outlet.
3. Your Flood Light Bar indicator light will flash.
4. Wait 30 seconds for the camera to go through its set-up mode. When the set-up mode is complete, you will hear the "Welcome to use" command.

# Setting Up Your



Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker

## Step 3: Connect Your Flood Light Bar to the App

1. Press the  sign in the App and then select **Add Device**.



2. You will see QR Scan in the HOMEi mobile app, use it to scan the QR Code on your Flood Light Bar.



3. Press and hold the Flood Light Bar button for 2 seconds until you hear a prompt tone. Then click Next step.



4. Enter your WiFi® information click Next step.





## Step 3: Connect Your Flood Light Bar to the App

5. Hold your phone with the QR code displayed directly in front of the Flood Light Bar until you hear a prompt sound.



6. The App will countdown until your Flood Light Bar and mobile device are connected to your Wi-Fi® network.



7. Enter a name for your Flood Light Bar ,then click Done.



8. Now,you are ready to start using your Flood Light Bar!



# Setting Up Your




Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker

## Step 4: Use Your Flood Light Bar

To get started, open your **HOMEi** app and follow these easy steps:

1. Choose the device you want to control.
2. Tap the image.
3. Tap the Light icon, one-button switch control light ON or OFF
4. Select your desired setting:
  - Smart Mode
  - Color Mode
  - B&W Mode







## How to use WIFI Amplifier ?

After your Flood Light Bar completes WiFi® connect, turn on the WiFi® setting in the mobile phone, search for the name : (I\_sound\_WiFi® )hotspot, and enter the password of your home WIFI router and you can use it now!

## How to use Sound Speaker?

1. When your Flood Light Bar is connected to the network, it will release the Bluetooth hotspot, turn on the Bluetooth setting in the mobile phone, and search for the Bluetooth name : I\_sound\_bar.
2. Click Connect Match, turn on your phone music and use it.
3. When you are watching live screen or operating the Flood Light Bar on APP, the Bluetooth speaker will not work, and it can be restored after exiting the operation.

# Setting Up Your



**Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker**

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or a qualified radio/TV technician for help.

# Setting Up Your



**Flood Light Bar with  
Wi-Fi® Amplifier,  
Camera & Sound Speaker**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### **FCC RF Radiation Exposure Statement Caution:**

To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

**FCC ID: 2A88H-0033052280**

**IC: 32423-ISB03**

**HVIN: ISB-03**



## Flood Light Bar with Wi-Fi® Amplifier, Camera & Sound Speaker



Wi-Fi®



Mobile  
Alert



2-Way  
Speaker



Motion  
Detection



Remote  
Viewing

FHD

Full HD  
3MP



Supports  
microSD Card



Color  
Night Vision



Secure  
App

For instructional videos and FAQ's please visit  
**[icustomerservice.com](http://icustomerservice.com) to learn more.**

Distributed by Trend Makers, LLC • Fort Walton Beach, FL 32547

©2024 Trend Makers, LLC

Made in China

All Rights Reserved.



**WARNING:** Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

By purchasing this product, you accept Trend Makers' terms and conditions including arbitration agreement.  
See enclosed for arbitration agreement. See [trendmakersinc.com/arbitration-agreement](http://trendmakersinc.com/arbitration-agreement) for details.